

VANISH™ FLOOR BODY INSTALLATION



1. Before pouring concrete around the Vanish™ body be sure the cap is on the body. Pour concrete in a 12"x12"x6" deep area and trowel smooth with the flange on the body and the finish level of the vermiculite. Be careful not to get concrete in the screw holes.



2. Place the seal ring within the body aligning the notches of the seal ring to the keys in the body. The seal ring is symmetrical and can be installed in either direction. Install the liner and make sure it is smoothed from the drain out past the area of the body you are working on.



3. Align the clamp ring over the body. There are 3 bumps on the body that corresponds with notches in the clamp ring (see step 2).



4. Once aligned, use the installation tool to uniformly seat the clamp ring to the body. Align cutout in tool for access to screw holes.



5. While firmly pressing down on tool with hand or knee, install two screws in opposite position evenly. Completely hand tighten screws. **DO NOT USE POWER TOOLS OR OVER TIGHTEN. MAX TORQUE (20 IN-LB.)**



6. Rotate the installation tool, press down again and install remaining screws in the order shown above.



7. Be sure each screw head is below the clamp ring gauge. **DO NOT OVER TIGHTEN.**



8. Trim the liner from the center of the body.



9. Using the other side of the installation tool, tighten the threaded trim ring to the body.



Paramount
Pool Life. Simplified.

295 East Corporate Place • Suite 100 • Chandler, AZ 85225
Toll Free: 1.800.621.5886 • Phone: 480.893.7607 • Fax: 480.753.3397
Paramount@1Paramount.com • www.1Paramount.com
US and Foreign patents and patents pending see www.1paramount.com/about/patents/